







Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	3055101	Spark plug				
2	4	005100906AR	Screw				
3	4	3833076	Washer				
4	1	50010215R	Decompressor				
5	2	098000004R	Piston ring Ø52				
6	1	094500007R	Piston pin				
7	2	007201198R	Ring				
8	1	098000312B	Piston assy Ø52				
9	1	50102012E	Complete cylinder				
10	1	52010458R	Gasket				
11	1	099900268A	Clamp				
12	1	52022079R	Cap				
13	1	006000010	Bearing				
14	1	098000001R	Crankshaft				
15	1	094500028R	Key				
16	1	097000009AR	Gasket				
17	1	094500004R	Seal ring				
18	1	52012112A	Crankcase				
19	2	099900006R	Bearing				
20	1	50200124R	Bush				
21	1	098000313	Grommet				
22	7	3833073R	Washer				
23	2	006100303R	Screw				
24	2	097000080BR	Stud				
25	1	099900014R	Seal ring				
26	4	3801015R	Screw				
27	1	097000132R	Clutch				
28	1	005100987	Screw				
29	1	097000098R	Spring				
30	1	097000057R	Grommet				
31	1	006000102	Cotter pin				
32	1	097000097	Washer				
33	1	52010030	Bearing				
34	1	52010035	Spacer				
35	1	52010034	Bushing				
36	1	52010029AR	Clutch drum				
37	2	3023008R	Plug				
38	1	52010134R	Plate				
39	1	52012044	Rod				
40	1	52010078AR	Starter lever				
41	1	3049030	O-ring				






Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	3801052R	Screw				
2	5	3033074	Washer				
3	1	097000342A	Cover				
4	2	3801045R	Screw				
5	2	005100913B	Screw				
6	2	3833073R	Washer				
7	1	098000133	Deflector				
8	1	098000132	Screen				
9	1	52010441A	Muffler				
10	1	097000094CR	Gasket				
11	1	52010120	Spring				
12	1	094600126	Tube				
13	2	61052009BR	Screw				
14	1	097000059A	Spring				
15	1	52010008A	Manifold				
16	1	097000333	Flange				
17	1	3960057R	Screw				
18	1	52012116A	Carburetor WJ-104				
19	1	015000100	Tube				
20	1	52010189	Screw guide				
21	3	097000092AR	Screw				
22	1	098000057	Support				
23	1	098000010	Manifold				






Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52010047	Handle				
2	2	097000061AR	Screw				
3	1	52010035	Spacer				
4	1	52010082	Breather valve				
5	1	093000448	Tube				
6	1	018500066	Fittings				
7	4	3801020	Screw				
8	1	018500096	Valve body				
9	1	098000319R	Tube				
10	1	52010092	Throttle kit				
11	1	52010077AR	Lever				
12	1	097000028R	Spring				
13	1	097000024	Cover				
14	3	3960040R	Screw				
15	1	099900090	O-ring				
16	1	52022005	Cap				
17	1	52010004	Guard				
18	1	3960087AR	Screw				
19	1	4098377R	Band				
20	1	52010214	Support				
21	2	018600197	Pin				
22	2	018600196A	Wheel				
23	1	52010253	Support				
24	4	3072015	Washer				
25	2	3801024	Screw				
26	6	097000038AR	AV-mount				
27	1	50200045BR	Complete tank				
28	1	50010218R	Fuel filter				
29	1	52010496R	Support				
30	1	3033074	Washer				






Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52010326BR	Flywheel				
2	2	52012027	Pawl kit				
3	1	005000361	Washer				
4	1	3833080	Washer				
5	1	004000142	Nut				
6	1	097000019C	Flange				BT7-015-09/07
7	1	094600169A	Spring				
8	1	094600097AR	Spark plug cap				
9	1	52010497R	Cable				
10	2	3916004R	Washer				
11	2	006000315R	Washer				
12	2	094000227	Screw				
13	1	52010320AR	Ignition coil				
14	1	50140060	Handle				BT7-015-09/07
15	1	098000079R	Starter rope				BT7-015-09/07
16	1	098000060AR	Spring				BT7-015-09/07
17	1	52010404	Spacer				BT7-015-09/07
18	6	3960017AR	Screw				BT7-015-09/07
19	1	50140055	Cover				BT7-015-09/07
20	1	3918006	Washer				BT7-015-09/07
21	1	52010439CR	Pulley				BT7-015-09/07
22	1	3908036	Screw				BT7-015-09/07
23	4	097000092AR	Screw				
24	1	52010495C	Starter kit				BT7-015-09/07
25	1	52010410	Cap				BT7-015-09/07
26	1	50140056	Cap				BT7-015-09/07
27	1	3960116	Screw				BT7-015-09/07
28	5	3819005R	Washer				BT7-015-09/07
29	1	52010495C	Starter kit				BT7-015-09/07
30	1	52012118BR	Complete spring				BT7-015-09/07
31	1	52010485BR	Starter pulley				BT7-015-09/07
32	1	52010489R	Cap				BT7-015-09/07
33	1	52010484BR	Flange				BT7-015-09/07
34	4	099900296R	Screw				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52010514R	Flange				
2	2	3049050R	O-ring				
3	1	52010513R	Air filter kit				
4	1	018600056AR	Air filter				
5	3	3802002A	Screw				
6	1	3049007	O-ring				
7	1	52010014B	Filter body				
8	1	52010451R	Air filter				
9	1	52010465	Tube and breather				
10	1	018600090A	Gasket				
11	1	52010059R	Gasket				
12	1	52010016AR	Clutch cover				
13	3	072700182	Screw				
14	3	3833073R	Washer				
15	1	52010132	Plate				
16	1	094500497R	Switch				
17	1	097000121A	Cable				
18	1	099900397	Nut				
19	1	004000438R	Plate				
20	1	52012004B	Cover				
21	1	52010060	Gasket				
22	1	52010041	Knob				
23	1	52010018A	Cover				
24	1	093000468A	Screw				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52010071R	Disk cover 12				
2	1	52010177	Screws kit				
3	1	52010312	Plate				
4	1	52010045	Ring				
5	1	018600235	Flange				
6	1	52010044	Spacer				
7	1	018600019	Shaft				
8	2	3806022R	Screw				
9	1	005000343	Washer				
10	1	018600236A	Flange				
11	1	018100029	O-ring				
12	2	3035042R	Bearing				
13	2	093000020	Washer				
14	5	094000251	Nut				
15	1	52010039	Spacer				
16	1	018600004A	Pulley				
17	1	3918013R	Washer				
18	1	3806065	Screw				
19	1	52010305	Plate				
20	10	3806021A	Screw				
21	1	52012114R	Arm				
22	1	52010043	Flange				
23	1	52010013	Clamp				
24	1	52010396	Sector				
25	1	52010430	Belt cover				
26	1	52010062AR	Knob				
27	2	3802005A	Screw				
28	1	52010025AR	Support				
29	2	3801016R	Screw				
30	3	3914010R	Nut				
31	2	50010148R	Nut				
32	1	018100180R	Belt				
33	1	52010022AR	Cover				
34	9	3833073R	Washer				
35	1	3906016R	Screw				
36	1	52010211	Guard				
37	1	52010046	Bushing				
38	1	52010401	Screw				
39	1	52010036	Belt tensioner				
40	10	3806021A	Screw				
41	1	3801066	Screw				
42	1	52010211	Guard				
43	2	3916008R	Washer				
44	1	006000300	Bushing				
45	1	3833080	Washer				
46	1	3906019R	Screw				
47	2	3980014R	Nut				
48	1	52022001AR	Arm assy 12				




48
 Braccio completo
 Complete arm
 Bras complet
 Brazo completo
 Komplett arm
 Ramie kompletne

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52010026	Disk cover 14				
2	1	52010177	Screws kit				
3	1	52010312	Plate				
4	1	52010045	Ring				
5	1	018600235	Flange				
6	1	52010044	Spacer				
7	1	018600019	Shaft				
8	2	3806022R	Screw				
9	1	005000343	Washer				
10	1	018600236A	Flange				
11	1	018100029	O-ring				
12	2	3035042R	Bearing				
13	2	093000020	Washer				
14	5	094000251	Nut				
15	1	52010039	Spacer				
16	1	018600004A	Pulley				
17	1	3918013R	Washer				
18	1	3806065	Screw				
19	1	52010305	Plate				
20	10	3806021A	Screw				
21	1	52012114R	Arm				
22	1	52010043	Flange				
23	1	52010013	Clamp				
24	1	52010396	Sector				
25	1	52010430	Belt cover				
26	1	52010062AR	Knob				
27	2	3802005A	Screw				
28	1	52010025AR	Support				
29	2	3801016R	Screw				
30	3	3914010R	Nut				
31	2	50010148R	Nut				
32	1	018100180R	Belt				
33	1	52010022AR	Cover				
34	9	3833073R	Washer				
35	1	3906016R	Screw				
36	1	52010211	Guard				
37	1	52010046	Bushing				
38	1	52010401	Screw				
39	1	52010036	Belt tensioner				
40	10	3806021A	Screw				
41	1	3801066	Screw				
42	1	52020019	Guard				
43	2	3916008R	Washer				
44	1	006000300	Bushing				
45	1	3833080	Washer				
46	1	3906019R	Screw				
47	2	3980014R	Nut				
48	1	52012006AR	Arm assy 14				









Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52010216AR	Disk cover 16				
2	1	52010177	Screws kit				
3	1	018600236A	Flange				
4	3	006000624	Screw				
5	1	018600235	Flange				
6	1	52010226R	Guard				
7	1	018100251	Pin				
8	4	3806022R	Screw				
9	7	3833073R	Washer				
10	1	018100012	Flange				
11	1	018100029	O-ring				
12	1	3035042R	Bearing				
13	1	018100020	Ring				
14	1	018600019	Shaft				
15	1	018600237	Spacer				
16	1	018600004A	Pulley				
17	1	3918013R	Washer				
18	1	3806065	Screw				
19	1	018100015	Pawl				
20	1	018100038	Spring				
21	1	018600009	Bracket				
22	1	018600015	Pin				
23	1	018600030	Spring				
24	1	006000300	Bushing				
25	1	52010431	Belt cover				
26	1	018600001	Arm				
27	1	006000156R	Screw				
28	1	094500034R	Washer				
29	1	3806065	Screw				
30	1	094600112	Nut				
31	4	50010148R	Nut				
32	1	018600031R	Belt				
33	1	018600003	Cover				
34	2	3916006R	Washer				
35	1	3801067	Screw				
36	1	52012060R	Arm assy				



▪25 Kit riparazione / Repair kit

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52010019	Shutter				
2	1	380000338	Screw				
3	1	52012116A	Carburetor WJ-104				
4	1	097000161	Spring				
5	1	097000154	Shaft				
6	1	097000155	Shaft				
7	1	097000162	Screw				
8	1	2318761	Screw L				
9	1	2318762	Screw H				
10	2	097000223	Spring				
11	2	097000224	Bushing				
12	5	035000162	Screw				
13	1	52010007	Cover				
14	1	003300202	Screw				
15	1	035000169	Spindle				
16	1	035000164	Spring				
17	1	006000325	Ball				
18	1	003300209	Screw				
19	1	035000151	Shutter				
20	1	035000149	Plate				
21	1	097000160	Lever				
22	1	003300036	Fittings				
23	1	097000157	Cover				
24	4	035000161	Screw				
25	1	2318672	Repair kit				
27	2	380000272	Seal ring				
28	1	015400153	Washer				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	52012055	Water kit				
2	1	52010110A	Water kit				
3	1	52012099	Labels kit				
3	1	52012102	Labels kit				
4	1	4191240	Tool kit				
5	1	52010173A	Flange				
6	-	-	Not available for this product				
7	1	098000408	Filter kit			Filtro in poliestere; Polyester filter	
8	2	3049050R	O-ring				